



**Woelky's Glass Studio**  
26323 Jefferson Ave. Suite F  
Murrieta, CA. 92562  
**714.287.6447**  
**Fax 951 304-3896**

## How To Install Glass Inserts Into Cabinet Frames Using Silicone

### **Step #1**

Prior to adding silicone to routed lip on the backside of the cabinet frame dry fit your Decorative Specialty Glass, Etched Glass or Leaded Glass Insert into the frame to make sure it fits correctly.



### **Step #2**

After you know the glass fits correctly remove the insert and add a small thin bead of clear silicone on the routed lip on the backside of the cabinet frame.



### **Step #3**

Place the insert into the backside of the cabinet frame and let dry at least 1 hour before hanging the cabinet door. If your cabinet frames are already installed you can follow all three steps but you must secure the glass insert in place with tape, we recommend blue painters tape to hold the insert in place while the silicone dries.

