



**Woelky's Glass Studio**  
26323 Jefferson Ave. Suite F  
Murrieta, CA. 92562  
**714.287.6447**  
**Fax 951 304-3896**

## How To Install Glass Inserts Into Cabinet Frames Using Silicone

**Important Note:** We do not recommend installing a Negative Etched Insert with a silicone sealant because if the silicone gets on the etched surface it will not come out. We recommend using the Metal Retaining Clip method of installation.

### **Step #1**

Prior to adding silicone to routed lip on the backside of the cabinet frame dry fit your Decorative Specialty Glass, Etched Glass or Leaded Glass Insert into the frame to make sure it fits correctly.



### **Step #2**

After you know the glass fits correctly remove the insert and add a small thin bead of clear silicone on the routed lip on the backside of the cabinet frame.



### **Step #3**

Place the insert into the backside of the cabinet frame and let dry at least 1 hour before hanging the cabinet door. If your cabinet frames are already installed you can follow all three steps but you must secure the glass insert in place with tape, we recommend blue painters tape to hold the insert in place while the silicone dries.





**Woelky's Glass Studio**  
26323 Jefferson Ave. Suite F  
Murrieta, CA. 92562  
**714.287.6447**  
**Fax 951 304-3896**

## Clear Silicone Information

The clear silicone tube shown below can be purchased at Home Depot.

Product Name: GE Silicone I Window and Door  
Size: 9.8 oz. Clear

GE Silicone I Window and Door offers outstanding performance in most applications. It is permanently flexible, and adheres to most woods, ceramics, glass, aluminum, and steel. Silicone I gives you a weatherproof/watertight seal around your windows, doors, air conditioners, and ductwork. Not recommended for masonry, concrete, stone, or oily woods.

